



## 2088 Series Parts Kit List



Model Number	1 Pressure Switch	2 Check Valve	3 Upper Housing	4 Valve Kit	Diaphragm Only	5 Drive/ Diaphragm Kit	6 Motor Kit	7 Upper Housing w/ Switch	8 Complete Pumphead Assembly
2088-443-144	94-230-35	94-237-00	94-231-30	94-232-00	N/A	94-238-03	11-111-00	94-231-20	N/A
2088-474-144	94-230-35	94-237-00	94-231-30	94-232-00	N/A	94-238-03	11-187-00	94-231-20	94-236-08
2088-594-154	94-230-35	94-237-00	94-231-30	94-232-00	N/A	94-238-03	11-150-10	94-231-20	94-236-21
2088-414-534	N/A	94-237-00	N/A	94-232-00	N/A	94-238-03	11-185-00	94-231-10	N/A
2088-574-534	N/A	94-237-00	N/A	94-232-00	N/A	94-238-03	11-181-00	94-231-10	N/A
2088-514-145	N/A	94-237-00	N/A	94-232-00	N/A	94-238-03	11-185-06	94-231-10	94-236-14

## 8000 Series Parts Kit List



Model Number	1 Complete Pump Assembly	2 Switch Assembly	3 Check Valve Assembly	4 Upper Housing	5/9 Bypass/ Non Bypass Valve Assembly	6 Diaphragm Assembly	7/10 Drive Assembly	8 Motor Assembly
8000-443-136	N/A	94-375-06	94-374-16	94-378-00	94-390-08	N/A	94-385-32	11-111-00
8000-443-236	N/A	94-375-06	94-374-16	94-379-00	94-390-08	N/A	94-385-32	11-111-00